

BLOW THROUGH VALVE

(ABSBOV - 27mm)



BISSON
THE PIPE FITTINGS EXPERTS

A blow off valve is positioned towards the end of a pipe run, it allows dust to be blown out of the system, by attaching a compressed air line and opening the valve.

Installation Instructions:

Use the correct solvent Plusbond 3019. Do not paint. Keep pipe clean and free from dust. Do not install in direct sunlight. Only install with approved pipe. Do not use solvents to clean, only soapy water.

PART NO.:
ABSBOV - 27mm

PIPE COLOUR:
Red

OPERATING TEMP:
- 40 c to 70 c'

INSIDE DIAMETER:
27mm

FITTINGS COLOUR:
Red

DIAMETER TOLERANCE:
+ / - 0.15mm'

WALL THICKNESS:
2mm

OUTSIDE DIAMETER:
27mm

